



SERIES DxA100




Mtrl.nr: 9814 10 52 • Ritn.nr: 7783 vers. A • Rev. 1910



Series DDA111
Series DAA111

LVD 2014/35/EU
EMC 2014/30/EU
RoHS 2011/65/EU
PED 2014/68/EU, article 4.3





ErP 2009/125/EU
ErP 2015
EnEV 2014



SERIES	FUNCTION
DAA111	
DDA111	





Electric installation




1

Remove actuator




2

Disassembly insulation




3

Wall mounting




4

Connecting the pipes




5

Mount the insulation




6a

Mount the actuator and cables





6b

Cabling




6c

Quick Fit




6d

Cabling • Dimensions




7

Mounting position



i


Application



8




By-pass ON/OFF



6 By-pass closed

6 By-pass open


Ø10 mm



9



Display



i



= Factory settings

10

Pump Settings

Click	LED display	Control mode	Pump curve
			Recommended Alternative
1		Constant speed	II
2		Constant speed	I
3		Variable differential pressure $\Delta p-v$	III
4		Variable differential pressure $\Delta p-v$	II
5		Variable differential pressure $\Delta p-v$	I
6		Constant differential pressure $\Delta p-v$	III
7		Constant differential pressure $\Delta p-v$	II
8		Constant differential pressure $\Delta p-v$	I
9		Constant speed	III


Pump features

1

2

3

4


Hold




LED display


Last settings


Status



Locked


Unlocked




Factory setting


Venting

Nameplate



Leaflet information



По вопросам продаж и технической поддержки обращайтесь:

сайт: esbe.pro-solution.ru эл. почта: ebs@pro-solution.ru телефон: 8 800 511 88 70

Астрахань: +7 (851) 299-46-80

Барнаул: +7 (385) 237-96-76

Белгород: +7 (472) 220-58-80

Владимир: +7 (492) 249-51-33

Волгоград: +7 (844) 245-94-42

Екатеринбург: +7 (343) 302-14-75

Ижевск: +7 (341) 220-90-75

Казань: +7 (843) 207-19-05

Калининград: +7 (401) 272-21-36

Кемерово: +7 (384) 221-56-70

Киров: +7 (833) 220-58-70

Краснодар: +7 (861) 238-86-59

Красноярск: +7 (391) 989-82-67

Курск: +7 (471) 223-80-45

Липецк: +7 (474) 220-01-75

Москва: +7 (499) 404-24-72

Набережные Челны: +7 (855) 291-01-32

Нижний Новгород: +7 (831) 200-34-65

Новосибирск: +7 (383) 235-95-48

Омск: +7 (381) 299-16-70

Оренбург: +7 (353) 248-64-35

Пермь: +7 (342) 233-81-65

Ростов-на-Дону: +7 (863) 309-14-65

Рязань: +7 (491) 277-61-95

Самара: +7 (846) 219-28-25

Санкт-Петербург: +7 (812) 660-57-09

Саратов: +7 (845) 239-86-35

Смоленск: +7 (481) 251-55-32

Ставрополь: +7 (865) 257-76-63

Сургут: +7 (346) 277-96-35

Тверь: +7 (482) 239-50-56

Тула: +7 (487) 244-05-30

Тюмень: +7 (345) 256-94-75

Ульяновск: +7 (842) 242-51-95

Уфа: +7 (347) 258-82-65

Хабаровск: +7 (421) 292-95-69

Чебоксары: +7 (835) 228-50-89

Челябинск: +7 (351) 277-89-65

Ярославль: +7 (485) 267-02-35

Россия и другие страны ТС. Доставка в любой город.